

Cyclone I (STR Cleat 2 Loop)

Features

- Third party certification to IEC 61914:2009
- Lightweight aluminium base with 316L stainless steel strap
- 24 - 145mm in 15 sizes for trefoil formation / application
- 36 - 118mm in 8 sizes for multicore cables or single core parallel formations
- 21 - 68mm in 8 sizes for quad formations
- Short circuit rating of 124kA peak fault
- Operating temperature -40°C to +60°C
- Low Smoke & Fume (LSF) liners as standard
- Combined single (M12) and two bolt (M10) base fixing design



www.cmp-products.com

FI500 REV 0 06/16




www.cmp-products.com

Cyclone I (STR Cleat 2 Loop)




**Cleat Installation
Instructions**


CMP Cleat Installation Instructions




1 Place cleat base onto ladder in desired location along rung




2 Place fitting(s) (1 x M10 or 2 x M10 - not supplied as standard), through the base and mounting surface




3 Tighten down to no more than 12 N/m torque




4 Place liner base on top




5 Place cables onto base



6 Wrap the liner around the cables and clip together



7 Place the strap through the base at the back and pull towards the front and loop two times around the cables



8 Place end of strap in to winding key and Start tightening the winding key until resistance is felt. Do not exceed the recommended torque of 12N/m



9 Align the holes of the winding key and retaining bush and put retaining pin through holes until it clips over bush, locking the winding key in place